SEAWARD

PrimeTest 50

Basic Pass/Fail handled unit for testing earth continuity and insulation resistance of appliances.

The PrimeTest 50 is lightweight and portable and features a greatly simplified range of tests. Simply choose the test you need – either earthed appliance, double-insulated appliance or mains cord testing. Its easy-to-read display is simple and registers PASS or FAIL. Connect the PrimeTest 50 to a power outlet and it will automatically check the socket wiring and mains voltage. It doesn't get much simpler.

Unlock extra features with our free and easy-to-use mobile app, PATMobile. Available for use on both Android and iOS devices, the handy app works with the PrimeTest 50 to enable the digital input and storage of pass/fail results alongside barcode scanning, label printing* and photo tagging.

The PrimeTest 50 is an obvious choice if you're looking for a reliable, portable safety tester that's effortless to use.

*Print label feature only available for Android devices

Key Features
- Simple to use push button operation
- Easy-to-read display with LCD display – shows simple pass/fail indication
- Accurate and reliable earth continuity testing
- Handheld and battery powered
- Compatible with free PATMobile app – enables you to log results, export your data, tag photos and print results*

Electrical/Analysis Test Functions
- Mains supply check
- IEC lead test
- Earth continuity (200mA)
- Insulation resistance (500V)

Ideal for
- Basic, low-volume testing

Get more from your manual PAT tester with our free and powerful mobile app.

Scan QR code to watch video

ANDROID APP ON
Google play

Available on the iPhone
App Store

www.seaward.co.uk/PrimeTest50
Tel: +44 (0) 191 587 8741
Email: sales@seaward.co.uk

Optional Accessory Kits Available		Part Number
PATBag Kit	■ Online PAT testing training course with exam ■ 30 day free trial of PATGuard Elements software ■ Durable, purpose-made PATBag with compartments for all of your PAT accessories and labels ■ 110V adaptor ■ 500 pass + 500 fail labels ■ Seaward Guide to PAT Testing ■ PAT reference look-up card ■ PAT logbook ■ Quick start video guide ■ PAT business builder CD-ROM and booklet Includes PrimeTest 50 PAT tester	345A929
PATBag Kit + PATGuard Elements software	The PATBag can optionally include PATGuard Elements manual data entry software – ideal for those who would like to keep an electronic register of assets and results including pass/fail results and retest dates.	345A930

Technical Specifications

Earth Continuity
Test Current	+/- 200mA DC
PASS/FAIL Threshold	0.2Ω

Insulation Resistance
Test Voltages	500VDC
PASS/FAIL Threshold	2MΩ

IEC Lead Test
Tests Performed	Earth continuity
	Insulation resistance
	Live, neutral continuity and polarity

Power Socket Test
Input Voltage Range	230V +10%, -15% AC
Indicators	Phase to earth voltage
	Phase to neutral voltage
	Neutral to earth

General Specifications

Dimensions	260 x 100 x 55mm (h x w x d)
Weight	800g
Power Source	6 x AA Batteries

Standard Accessories (supplied with PrimeTest 50)
0.5m extension adaptor	Earth bond lead
6 x AA batteries	Carry case

Optional Accessories
PATGuard Elements software (387A910)
Test n Tag Pro Bluetooth/Serial printer with small (52 x 25mm) labels (compatible via PATMobile app, Android version only) (339A987)
Roll of small labels (approx. 350 off 52x25mm labels) (339A947)
110V to IEC adaptor (344A050)
230 to 110V adaptor (270A076)
3 phase adaptor – 16A 4 pin 415V (for Rpe & IR) (209A910)
3 phase adaptor – 16A 5 pin 415V (for Rpe & IR) (209A911)
3 phase adaptor – 32A 4 pin 415V (for Rpe & IR) (209A912)
3 phase adaptor – 32A 5 pin 415V (for Rpe & IR) (209A913)
PAT checkbox (227A910)
PowerCheck 1557 (369A910)
1000 x Pass labels (91B038)
1000 x Fail labels (91B311)
100 x Rhinotags (91B309)
250 x Barcode appliance no. labels (compatible via PATMobile app, Android version only) (194A307)
Rechargeable batteries and charger (339A950)

Training
Seaward offer a range of PAT testing courses, including City & Guilds. Go to **www.seaward.co.uk/training** for more information.

Services
1 year warranty subject to product registration with Seaward, visit **www.seaward.co.uk/register-product**

Service and calibration by Calibrationhouse.
Go to **www.calibrationhouse.com** for more information.

Part Numbers
PrimeTest 50	347A910
PrimeTest 50 PATbag kit	345A929
PrimeTest 50 PATbag kit + PATGuard Elements	345A930

Also Available in this Range
PrimeTest 100	344A910
PrimeTest 250+	403A910

www.seaward.co.uk/PrimeTest50
Tel: +44 (0) 191 587 8741
Email: sales@seaward.co.uk

Rev 2